

Warnings

- Be sure to use cordless tools when near to or in water.
- Assembly is heavy. Be sure to use proper lifting technique.
- Always use three Poly Flange Floats per dock section.
- Make sure that all 18 screws are tightened correctly.

Assembling Instructions

1. Place your dock on an even surface with the deck side down.
2. Center one float (A) (**Picture 1**).
3. When centered, insert the six self tapping screws (B). Please note recommended order in illustration (**Picture 1**).
4. Now place the other two floats (A) in even distances to the center float (A). Keep enough distance to the end rails to install brackets (**Picture 2**).
5. Insert six self tapping screws (B) per float. Please follow the recommended order (**Picture 1**).
6. Flip the deck over.

Now attach the brackets to your Tommy Docks Floating Dock. It is strongly recommended that you use only the Tommy Docks 1 1/2" brackets combined with Tommy Docks 1 1/4" pipes to prevent binding between brackets and pipes.

Parts

- A** 2' x 4' x 16" Poly Flange Float (3)
- B** Stainless 12-14 x 1-1/2" Self Drilling Screw (18) sold separately

Recommended Tools and Hardware:

1. Cordless Drill
2. 5/16" Nut Driver
3. Tape Measure
4. Stainless 12-14 x 1-1/2" Self Drilling Screw (18)

